

AD-A187 712

SHELF LIFE DEGRADATION OF SELECTED ANAEROBIC
THREADLOCKING ADHESIVES AT U. S. ARMY LAB COMMAND
WATERLOO, ONTARIO MATERIAL TECHNOLOGY LAB
P. A. BENQUIST ET AL. SEP 87 MIL-TR-87-51

1/1

UNCLASSIFIED

F/G 11/1


NL

END

DATE

FORMED

28



MICROCOPY RESOLUTION TEST CHART
 NATIONAL BUREAU OF STANDARDS-1963-A

AD-A187 712

MTL TR 87-51

AD

2

DTIC FILE COPY

SHELF LIFE DEGRADATION OF SELECTED ANAEROBIC THREADLOCKING ADHESIVES AT VARIOUS STORAGE TEMPERATURES

PAUL R. BERGQUIST and STANLEY E. WENTWORTH
POLYMER RESEARCH DIVISION

September 1987

DTIC
ELECTE
DEC 21 1987
S D
C&D

Approved for public release; distribution unlimited.



US ARMY
LABORATORY COMMAND
MATERIALS TECHNOLOGY
LABORATORY

87 12 11 044

U.S. ARMY MATERIALS TECHNOLOGY LABORATORY
Watertown, Massachusetts 02172-0001

The findings in this report are not to be construed as an official Department of the Army position, unless so designated by other authorized documents.

Mention of any trade names or manufacturers in this report shall not be construed as advertising nor as an official indorsement or approval of such products or companies by the United States Government.

DISPOSITION INSTRUCTIONS

Destroy this report when it is no longer needed.
Do not return it to the originator.

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

DD FORM 1473
1 JAN 73

EDITION OF 1 NOV 65 IS OBSOLETE

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

Block No. 20

ABSTRACT

↙ This study addresses the shelf life degradation of three commercially available anaerobic adhesives maintained at 0°C, 22°C, and 50°C. A titrimetric procedure was developed to monitor the change in the adhesive peroxide initiator concentration over an 18 month period. The change was then related to a corresponding decrease in the breakaway and prevailing torque strengths of bonded nuts and bolts prepared with the aged adhesives. It was determined that elevated temperature storage caused degradation of the adhesives and that the titrimetric method could be useful as a quality control method where such storage may be unavoidable. *h. m. m. m. m.*

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

CONTENTS

	Page
INTRODUCTION.	1
EXPERIMENTAL	
Sample Acquisition and Storage	2
Torque Measurements.	2
Peroxide Determination	2
Instrumentation.	3
RESULTS AND DISCUSSION	
50°C Storage	4
22°C Storage	4
0°C Storage.	4
Failure Criteria	4
SUMMARY AND CONCLUSION.	8



ACCOMMOD FOR	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution	
Availability Codes	
Dist	Avail and or Spec
A-1	

INTRODUCTION

Mechanical fasteners often loosen as a result of prolonged vibration and intermittent shock. Overcoming this problem through the use of anaerobic adhesives represents a 50 percent cost savings over the mechanical split lock washer and additional savings on the maintenance time required to retighten loose bolts or fasteners.

This study deals with the shelf life degradation of anaerobic adhesives prior to application. It is an extension of an earlier project that addressed the chemical composition of some 45 commercial anaerobic adhesive and sealant formulations.* This earlier work indicated that the shelf life degradation of the uncured adhesives was very likely to influence the curing behavior of the adhesive and the mechanical properties of adhesively bonded specimens.

Anaerobic adhesives are complex formulations that contain an unsaturated oligomeric base resin and a peroxidic initiator. In addition, they contain fillers, reactive diluents, accelerators, inhibitors, bond strength enhancers, and viscosity modifiers. Subtle changes in the concentration, the number of components present, or the nature of the components, can result in profound changes in the ability to cure, as well as the physical properties of the cured adhesive. Both qualitative and quantitative analyses of each component would be required to thoroughly study just one adhesive formulation. Even then, it would be difficult, if not impossible, to determine which component or combination of components directly affected the mechanical strength of the cured adhesive.

However, it was felt that monitoring the concentration of the peroxide cure initiator, the least stable and most important component, would provide a good indication of deterioration of the adhesive, especially when correlated with break-away and prevailing torque data. No data was available as to the rate or effect of such degradation on subsequent bonding performance. Thus, a detailed study was undertaken to determine the effect of shelf-storage on chemical composition and mechanical properties of several representative anaerobic adhesive formulations.

After evaluating various standard methods¹⁻⁵ and conducting a literature survey on methods for the analysis of organic peroxides, it was concluded that, without modification, none of them would meet our requirements for a quick, simple, and accurate means of determining organic peroxides in complex mixtures. Therefore, a modified wet-potentiometric titration method was developed.⁵

*WENTWORTH, S.F. Unpublished work.

1. *Assay of Organic Peroxides, Method A*. 1979 Annual Book of ASTM Standards, ASTM E-298, part 30, p. 830-831.
2. *Assay of Organic Peroxides, Method B*. 1979 Annual Book of ASTM Standards, ASTM E-298, part 30, p. 832-833.
3. *Standard Test Method for Traces of Peroxides in Organic Solvents With N,N'-Diphenyl-p-P-onylenediamine*. 1979 Annual Book of ASTM Standards, ASTM E-440, part 30, p. 956-959.
4. *Standard Test Method for Trace Amounts of Peroxides in Organic Solvents*. 1979 Annual Book of ASTM Standards, ASTM E-299, part 30, p. 834-837.
5. *Assay of Di-Ter-Butyl Peroxide by Gas Chromatographic Analysis*. 1979 Annual Book of ASTM Standards, ASTM E-475, part 30, p. 984-987.
6. CHIN, W. and BERGQUIST, P.R. *Method Development for the Analysis of Cumene Hydroperoxide in an Anaerobic-Adhesive System*. To be submitted for publication as a technical report.

EXPERIMENTAL

Sample Acquisition and Storage

Six 50 ml plastic bottles of each of the three commercial adhesives presented in Table 1 were purchased from local distributors. The adhesives to be studied were selected as representative of commercial threadlocking formulations. Two of the adhesive formulations (Adhesives B and C) contain cumene hydroperoxide as the peroxide initiator, while all three anaerobic adhesives have tetraethylene glycol dimethacrylate present as the base resin.

Table 1. ADHESIVES STUDIED

Adhesive	Viscosity	Color*	Type*	Grade*
A	150 cps	Blue	I	J
B	900-1300 cps	Blue	II	N
C	900-1300 cps	Blue	II	N

*The classification of type and grade are based on MIL-S-46163A.

After initial determination of the peroxide concentration and torque values, the adhesives were stored in controlled environments at possible depot storage temperatures. Three bottles of each adhesive were stored at 50°C, two bottles of each at 22°C, and one bottle of each at 0°C. Samples were withdrawn and analyzed at intervals (frequency and duration dependent on initial results) to determine how the composition was changing. Mechanical test specimens were prepared and tested concurrently.

Torque Measurements

The torque measurements consisted of bonding a nut and bolt and testing the torque required to break the bond and maintain rotation after break. The mechanical test specimens were prepared and tested according to MIL-S-46163A, sections 4.6.2.1.1 and 4.6.2.1.2. The resulting breakaway torque and prevailing torque based on five specimens were measured at an initial quarter turn and as the average of the next four quarter turns. The values are reported in inch-lbs.

Peroxide Determination

The bottles were well shaken before sampling. Approximately 0.50 grams of sample was weighed into a 250 ml erlenmeyer flask before adding 25 ml of isopropanol. The flask was capped and swirled. Four milliliters of glacial acetic acid was added, and the flask was again capped and swirled before adding 10 ml of saturated sodium iodide in isopropanol. The flask was connected to a condenser and the contents allowed to reflux with stirring for 7 minutes. The condenser was washed down with 5 ml of water. Finally, the flask was cooled in cold water to room temperature. The total time from start to finish was 10 minutes.

The solution was titrated with a 0.01 N standardized sodium thiosulfate solution using a redox electrode-pH meter setup. A blank of the above reagents was run. The calculation of percent peroxide is as follows:

$$\% \text{ Peroxide Content (Calculated as Cumene Hydroperoxide*)} = \frac{(A-B)(N)(M.W.)(100)}{(WGT)(2C)(1000)}$$

where

A = milliliters of $\text{Na}_2\text{S}_2\text{O}_3$ titrant required for sample
 B = milliliters of $\text{Na}_2\text{S}_2\text{O}_3$ titrant required for blank
 C = number of peroxide groups in the peroxide compound
 N = normality of $\text{Na}_2\text{S}_2\text{O}_3$
 M.W. = molecular weight of the peroxide compound
 WGT = gram weight of sample used

The accuracy and precision of the titration method were established by analyzing a model anaerobic formulation consisting of tetraethylene glycol dimethacrylate and a known concentration of cumene hydroperoxide. Based on the average deviation for this method, the percentage of error for the experimentally determined value is +1.3%

Instrumentation

Corning Model 150 pH Meter/ion meter, automatic

Orion electrode, combination, redox (977800)

APCO-Mossberg Torque Wrench RDI-150

APCO-Mossberg Torque Wrench RDI-75

RESULTS AND DISCUSSION

After the initial baseline data was determined, the adhesives were placed in storage in controlled environments simulating extreme service storage conditions. The initial characterization and mechanical test data is presented in Table 2.

Table 2. ADHESIVE BASELINE DATA

Adhesive	Peroxide Concentration (%)	Breakaway Torque (inch-lbs)	Prevailing Torque (inch-lbs)
A	1.47	118	38.4
B	1.59	115	39.6
C	2.59	107	36.6

*Cumene hydroperoxide has a molecular weight of 152 with one peroxide group in the molecule.

50°C Storage

The anaerobic adhesives maintained at 50°C are the only adhesives to show any real change in percent reported cumene hydroperoxide concentration and torque values during this 574 day study. Adhesive A (Figures 1 and 2) was the first material to exhibit a change in both peroxide concentration and torque values. The initiator concentration decreased from an initial average value of 1.47% to 0.82% after 127 days. Illustrated in Figure 2 is the decline in the breakaway torque for materials stored at 50°C. As can be seen, the breakaway torque for Adhesive A drops from an initial average value of 118 to 14 inch-lbs after 127 days. The prevailing torque (Figure 3) declined from 38.4 to 4 inch-lbs in the same time period.

Adhesive C also exhibited a significant change in torque values (Figures 2 and 3). The peroxide concentration steadily decreased from an initial value of 2.59% to 0.41% after 513 days. The initial breakaway torque and prevailing torque were 107 and 36.6 inch-lbs respectively. The breakaway torque remained relatively constant for initiator concentrations above 0.74%.

Adhesive B demonstrated a steady decline in peroxide concentration from an initial value of 1.59% to 0.35% after 513 days, but exhibited no discernable change in torque values. The average initial breakaway torque for Adhesive B is 115 inch-lbs with a prevailing torque of 39.6 inch-lbs.

During the course of this study, several observations were made on the adhesives in storage at 50°C. After 33 days, the bottles became oily to the touch. Some component or components appear to be migrating through the polyethylene walls of the bottle. The labeling information on the bottles of Adhesive A rubs off when touched. After 395 days, it was observed that Adhesive C had changed color from blue to pale green, an important factor, since color is used to designate strength range for application uses.

22°C Storage

Even though some of the anaerobic adhesives stored at 22°C exhibit a change in peroxide concentration (Figure 4), their torque values failed to show any significant change (Figures 5 and 6). During 513 days at 22°C, the peroxide concentration for Adhesive A steadily decreased from 1.47% to 1.08%. Adhesive C displayed a very slight change in peroxide concentration from 2.59% to 2.53%.

0°C Storage

Except for Adhesive A, the anaerobic adhesives stored at 0°C show no change in cumene hydroperoxide concentration or torque values. The reported cumene hydroperoxide concentration for Adhesive A had changed only slightly from 1.47% to 1.37% after 513 days.

Failure Criteria

Anaerobic adhesives are accepted by the government based upon their ability to meet the requirements set forth in MIL-S-46163A, and discarded when they have exceeded their expiration date. According to the MIL-SPEC, anaerobic adhesive products can be rejected if they deviate from the criteria in color, viscosity, flash point, smoothness and homogeneity, packaging, solubility, wettability, corrosivity, toxicity, lubricity, ultraviolet illumination, storage stability, or speed of cure.




Figure 1. Change in peroxide concentration during storage at 50°C.




Figure 2. Breakaway torque values for anaerobic adhesives stored at 50°C.




Figure 3. Prevailing torque values for anaerobic adhesives stored at 50°C.




Figure 4. Change in peroxide concentration during storage at 22°C.




Figure 5. Breakaway torque values for anaerobic adhesives stored at 22°C.




Figure 6. Prevailing torque values for anaerobic adhesives stored at 22°C.

The polymerized adhesive must also meet standards for locking torque after cure, locking torque after immersion in solvents, hot strength, heat aging, low temperature torque, fluid tightness, and fungus resistance.

The point of failure or rejection of the adhesive occurs when the breakaway and prevailing torque measurements fall outside allowable ranges. The range of acceptable torque values is listed in MIL-S-46163A for adhesives classified as a particular type and grade before color coding. The type and grade are based on viscosity and locking torque. Ambiguities arise when classifying the adhesives based on viscosity, because the MIL SPEC does not specify a standard spindle size and speed. The reported viscosity, as measured by a Brookfield viscometer, varies with rotation speed and spindle size. For the adhesives used in this study, there is no clear-cut classification of these materials. Thus, the point of failure was arbitrarily taken as the point where the breakaway torque strength had dropped to 50 percent of the baseline torque.

Based on the above criteria, the failure behavior was evaluated for the adhesives stored at 50°C. Adhesive A is considered to have failed after 85 days. This corresponds to a breakaway torque of 59.2 inch-lbs, a prevailing torque of 19.2 inch-lbs, and an initiator concentration value of 0.94%. The torque values for Adhesive C remained relatively constant before showing a downward trend after 375 days. The adhesive finally reached the point of failure after 513 days at a breakaway torque of 49.6 inch-lbs with a prevailing torque of 13.9 inch-lbs and a corresponding reported cumene hydroperoxide concentration of 0.41%. The initiator concentration for Adhesive C dropped off more gradually than Adhesive A. The only adhesive to exhibit a color change was Adhesive C with a noticed change from blue to green after 395 days. It should be noted that the color change in itself is cause for rejection. Adhesive B has perhaps the most forgiving formulation. The torque values remained unchanged even though the initiator concentration reached a value of 0.35% after 572 days. The breakaway torque values appear to remain constant, and exhibit change only after the initiator concentration has dropped below its threshold value where a decrease in the mechanical properties is observed.

The peroxide concentration for the adhesives stored at 22°C changed at a very slow rate. The only adhesive at 22°C that might exhibit a change in its torque values within a reasonable period of time is Adhesive A, but this would be expected to require 4 or 5 additional months based on the apparent rate of decline (Figure 4).

The torque values (Figures 2, 3, 5 and 6) initially appear to increase. This may be due to inadequate surface preparation. The torque measurements on the nut and bolt specimens used in this study yielded values that have an average deviation as high as +13 inch-lbs. This resulted in the scattering of the data points and difficulty in accurately determining the exact point of failure.

SUMMARY AND CONCLUSION

The adhesive bond exhibits mechanical failure once a limiting or critical initiator concentration particular to that adhesive is reached (Figures 7-9). Only those anaerobic adhesives stored at 50°C exhibited a sufficiently rapid rate of initiator deterioration to warrant concern for shelf life. Under depot storage conditions, elevated temperatures may be unavoidable. Adhesive A would have initially passed the MIL-SPEC requirements but would have failed after 85 days of




Figure 7. Breakaway torque versus peroxide concentration at 50°C.




Figure 8. Breakaway torque versus peroxide concentration at 50°C.

storage* at 50°C, while Adhesives B and C had long shelf lives. The wet-potentiometric method could be useful as a quality control technique for assessing the residual shelf life of the anaerobic adhesive. The advantages of the method lie in its simplicity and speed. Although the wet-potentiometric method would not replace existing quality control tests, it would yield information relating fundamental chemical changes to observed mechanical responses. Thus, knowledge of the residual shelf life would prevent premature disposal of these relatively expensive materials. For the method of analysis to be applicable, a mastercurve depicting the relationship between the physical responses and the chemical changes must first be established. A frequently utilized adhesive with a high volume use could make the wet-potentiometric method a cost effective quality control technique.




Figure 9. Breakaway torque versus peroxide concentration at 50°C.

*Since the adhesives were obtained from distributors, not from manufacturers, there is no guarantee of the exact storage conditions or time since manufacture.

DISTRIBUTION LIST

No. of Copies	To
1	Office of the Under Secretary of Defense for Research and Engineering, The Pentagon, Washington, DC 20301
	Commander, U.S. Army Laboratory Command, 2800 Powder Mill Road, Adelphi, MD 20783-1145
1	ATTN: SLCIS-IM-TL
	Commander, Defense Technical Information Center, Cameron Station, Building 5, 5010 Duke Street, Alexandria, VA 22304-6145
2	ATTN: DTIC-FDAC
1	Metals and Ceramics Information Center, Battelle Columbus Laboratories, 505 King Avenue, Columbus, OH 43201
	Commander, Army Research Office, P.O. Box 12211, Research Triangle Park, NC 27709-2211
1	ATTN: Information Processing Office
	Commander, U.S. Army Materiel Command, 5001 Eisenhower Avenue, Alexandria, VA 22333
1	ATTN: AMCLD
	Commander, U.S. Army Materiel Systems Analysis Activity, Aberdeen Proving Ground, MD 21005
1	ATTN: AMXSYP, H. Cohen
	Commander, U.S. Army Electronics Research and Development Command, Fort Monmouth, NJ 07703
1	ATTN: AMDSD-L
1	AMDSD-E
	Commander, U.S. Army Missile Command, Redstone Scientific Information Center, Redstone Arsenal, AL 35898-5241
1	ATTN: AMSMI-RKP, J. Wright, Bldg. 7574
1	AMSMI-RD-CS-R/ILL Open Lit
1	AMSMI-RLM
	Commander, U.S. Army Armament, Munitions and Chemical Command, Dover, NJ 07801
2	ATTN: Technical Library
1	AMDAR-LCA, Mr. Harry E. Peibly, Jr., PLASTEC, Director
	Commander, U.S. Army Natick Research, Development, and Engineering Center, Natick, MA 01760
1	ATTN: Technical Library
	Commander, U.S. Army Satellite Communications Agency, Fort Monmouth, NJ 07703
1	ATTN: Technical Document Center
	Commander, U.S. Army Tank-Automotive Command, Warren, MI 48090
1	ATTN: AMSTA-ZSK
2	AMSTA-TSL, Technical Library
	Commander, White Sands Missile Range, NM 88002
1	ATTN: STEWS-WS-VT
	President, Airborne, Electronics and Special Warfare Board, Fort Bragg, NC 28307
1	ATTN: Library
	Director, U.S. Army Ballistic Research Laboratory, Aberdeen Proving Ground, MD 21005
1	ATTN: AMDAR-TSB-S (STINFO)
	Commander, Dugway Proving Ground, Dugway, UT 84022
1	ATTN: Technical Library, Technical Information Division
	Commander, Harry Diamond Laboratories, 2800 Powder Mill Road, Adelphi, MD 20783
1	ATTN: Technical Information Office

No. of Copies	To
1	Director, Benet Weapons Laboratory, LCWSL, USA AMCCOM, Watervliet, NY 12189
1	ATTN: AMSMC-LCB-TL
1	AMSMC-LCB-R
1	AMSMC-LCB-RM
1	AMSMC-LCB-RP
1	Commander, U.S. Army Foreign Science and Technology Center, 220 7th Street, N.E., Charlottesville, VA 22901
1	ATTN: Military Tech
1	Commander, U.S. Army Aeromedical Research Unit, P.O. Box 577, Fort Rucker, AL 36360
1	ATTN: Technical Library
1	Director, Eustis Directorate, U.S. Army Air Mobility Research and Development Laboratory, Fort Eustis, VA 23604-5577
1	ATTN: SAVDL-E-MOS (AVSCOM)
1	U.S. Army Aviation Training Library, Fort Rucker, AL 36360
1	ATTN: Building 5906-5907
1	Commander, U.S. Army Agency for Aviation Safety, Fort Rucker, AL 36362
1	ATTN: Technical Library
1	Commander, USACDC Air Defense Agency, Fort Bliss, TX 79916
1	ATTN: Technical Library
1	Commander, U.S. Army Engineer School, Fort Belvoir, VA 22060
1	ATTN: Library
1	Commander, U.S. Army Engineer Waterways Experiment Station, P. O. Box 631, Vicksburg, MS 39180
1	ATTN: Research Center Library
1	Technical Director, Human Engineering Laboratories, Aberdeen Proving Ground, MD 21005
1	ATTN: Technical Reports Office
1	Commandant, U.S. Army Quartermaster School, Fort Lee, VA 23801
1	ATTN: Quartermaster School Library
1	Naval Research Laboratory, Washington, DC 20375
1	ATTN: Code 5830
2	Dr. G. R. Yoder - Code 6384
1	Chief of Naval Research, Arlington, VA 22217
1	ATTN: Code 471
1	Edward J. Morrissey, AFWAL/MLTE, Wright-Patterson Air Force, Base, OH 45433
1	Commander, U.S. Air Force Wright Aeronautical Laboratories, Wright-Patterson Air Force Base, OH 45433
1	ATTN: AFWAL/MLC
1	AFWAL/MLLP, M. Forney, Jr.
1	AFWAL/MLBC, Mr. Stanley Schulman
1	National Aeronautics and Space Administration, Marshall Space Flight Center, Huntsville, AL 35812
1	ATTN: R. J. Schwinghammer, EH01, Dir, M&P Lab
1	Mr. W. A. Wilson, EH41, Bldg. 4612
1	U.S. Department of Commerce, National Bureau of Standards, Gaithersburg, MD 20899
1	ATTN: Stephen M. Hsu, Chief, Ceramics Division, Institute for Materials Science and Engineering
1	Committee on Marine Structures, Marine Board, National Research Council, 2101 Constitution Ave., N.W., Washington, DC 20418

No. of Copies	To
1	Librarian, Materials Sciences Corporation, Guynedd Plaza 11, Bethlehem Pike, Spring House, PA 19477
1	The Charles Stark Draper Laboratory, 68 Albany Street, Cambridge, MA 02139
	Wyman-Gordon Company, Worcester, MA 01601
1	ATTN: Technical Library
	Lockheed-Georgia Company, 86 South Cobb Drive, Marietta, GA 30063
1	ATTN: Materials and Processes Engineering Dept. 71-11, Zone 54
	General Dynamics, Convair Aerospace Division, P.O. Box 748, Fort Worth, TX 76101
1	ATTN: Mfg. Engineering Technical Library
1	Mechanical Properties Data Center, Belfour Stulen Inc., 13917 W. Bay Shore Drive, Traverse City, MI 49684
1	Mr. R. J. Zentner, EAI Corporation, 198 Thomas Johnson Drive, Suite 16, Frederick, MD 21701
1	Dr. James Economy, IBM Corporation, K42-282, Monterey and Cottle Road, San Jose, CA 95114
1	Professor George B. Butler, Department of Chemistry, University of Florida, Gainesville, FL 32601
1	Professor Nathan D. Field, Department of Chemical Engineering, The City College of the City University of New York, 38th Street & Convent Avenue, New York City, NY 10031
1	Professor John K. Gillham, Department of Chemical Engineering, Princeton University, Princeton, NJ 08540
1	Professor Morton H. Litt, Department of Macromolecular Science, Case Western Reserve University, Cleveland, OH 44106
1	Dr. Stanley M. Barkin, Staff Scientist, National Materials Advisory Board, National Academy of Sciences, 2101 Constitution Avenue, N.W., Washington, DC 20418
1	Dr. John T. Quinlivan, The Boeing Company, P.O. Box 3707, M.S. 4456, Seattle, WA 98124
1	Professor Garth L. Wilkes, Department of Chemical Engineering, Virginia Polytechnic Institute & State University, Blacksburg, VA 24061
1	Mr. Ted Reinhart, Chief, Composites, Adhesives, & Fibrous Materials Branch, Air Force Wright Aeronautical Laboratories (AFSC), Wright-Patterson Air Force Base, OH 45433
1	Dr. Robert Bikales, Director, Polymers Program, National Science Foundation, 1800 G Street, N.W., Washington, DC 10550
1	Dr. Norman J. Johnston, Head, Polymer Section, Langley Research Center, Langley Station, Hampton, VA 23665
1	Dr. Bruno Fanconi, Leader, Structure and Properties Group, Polymer Sciences and Standards Division, National Bureau of Standards, Room A 209, Building 224, Washington, DC 20234
	Director, U.S. Army Materials Technology Laboratory, Watertown, MA 02172-0001
2	ATTN: SLCMT-IML
2	Authors

J.S. Army Materials Technology Laboratory
Watertown, Massachusetts 02172-0001

SHelf LIFE DEGRADATION OF SELECTED ANAEROBIC
THREAULOCKING ADHESIVES AT VARIOUS STORAGE
TEMPERATURES -

Paul R. Bergquist and Stanley E. Wentworth

Technical Report MIL TR 97-51, September 1987, 13 pp -
illustrations

UNCLASSIFIED
UNLIMITED DISTRIBUTION

Key Words

adhesives
Anaerobic adhesives
Adhesive bonding

This study addresses the shelf life degradation of three commercially available anaerobic adhesives maintained at 0°C, 22°C, and 50°C. A titrimetric procedure was developed to monitor the change in the adhesive peroxide initiator concentration over an 18 month period. The change was then related to a corresponding decrease in the breakaway and prevailing torque strengths of bonded nuts and bolts prepared with the aged adhesives. It was determined that elevated temperature storage caused degradation of the adhesives and that the titrimetric method could be useful as a quality control method where such storage may be unavoidable.

J.S. Army Materials Technology Laboratory
Watertown, Massachusetts 02172-0001

SHelf LIFE DEGRADATION OF SELECTED ANAEROBIC
THREAULOCKING ADHESIVES AT VARIOUS STORAGE
TEMPERATURES -

Paul R. Bergquist and Stanley E. Wentworth

Technical Report MIL TR 97-51, September 1987, 13 pp -
illustrations

UNCLASSIFIED
UNLIMITED DISTRIBUTION

Key Words

adhesives
Anaerobic adhesives
Adhesive bonding

This study addresses the shelf life degradation of three commercially available anaerobic adhesives maintained at 0°C, 22°C, and 50°C. A titrimetric procedure was developed to monitor the change in the adhesive peroxide initiator concentration over an 18 month period. The change was then related to a corresponding decrease in the breakaway and prevailing torque strengths of bonded nuts and bolts prepared with the aged adhesives. It was determined that elevated temperature storage caused degradation of the adhesives and that the titrimetric method could be useful as a quality control method where such storage may be unavoidable.

J.S. Army Materials Technology Laboratory
Watertown, Massachusetts 02172-0001

SHelf LIFE DEGRADATION OF SELECTED ANAEROBIC
THREAULOCKING ADHESIVES AT VARIOUS STORAGE
TEMPERATURES -

Paul R. Bergquist and Stanley E. Wentworth

Technical Report MIL TR 97-51, September 1987, 13 pp -
illustrations

AD

UNCLASSIFIED
UNLIMITED DISTRIBUTION

Key Words

adhesives
Anaerobic adhesives
Adhesive bonding

This study addresses the shelf life degradation of three commercially available anaerobic adhesives maintained at 0°C, 22°C, and 50°C. A titrimetric procedure was developed to monitor the change in the adhesive peroxide initiator concentration over an 18 month period. The change was then related to a corresponding decrease in the breakaway and prevailing torque strengths of bonded nuts and bolts prepared with the aged adhesives. It was determined that elevated temperature storage caused degradation of the adhesives and that the titrimetric method could be useful as a quality control method where such storage may be unavoidable.

J.S. Army Materials Technology Laboratory
Watertown, Massachusetts 02172-0001

SHelf LIFE DEGRADATION OF SELECTED ANAEROBIC
THREAULOCKING ADHESIVES AT VARIOUS STORAGE
TEMPERATURES -

Paul R. Bergquist and Stanley E. Wentworth

Technical Report MIL TR 97-51, September 1987, 13 pp -
illustrations

AD

UNCLASSIFIED
UNLIMITED DISTRIBUTION

Key Words

adhesives
Anaerobic adhesives
Adhesive bonding

This study addresses the shelf life degradation of three commercially available anaerobic adhesives maintained at 0°C, 22°C, and 50°C. A titrimetric procedure was developed to monitor the change in the adhesive peroxide initiator concentration over an 18 month period. The change was then related to a corresponding decrease in the breakaway and prevailing torque strengths of bonded nuts and bolts prepared with the aged adhesives. It was determined that elevated temperature storage caused degradation of the adhesives and that the titrimetric method could be useful as a quality control method where such storage may be unavoidable.

DATE
FILMED
8

